



Congratulations on your purchase of *The ArchAngle Banner*! *The ArchAngle* is designed to give you outstanding service as an attention grabbing marketing device that is sure to flag down your potential customers.

### Installing The ArchAngle

1 - Your *ArchAngle* kit includes: Three Pole Sections, Printed Message Banner, 360° Swivel Ground Stake and Carrying Bag.

2 - Carefully unpack the bag contents.

3 - Select area to mount the *Ground Stake* making sure that adequate clearance is available for *The ArchAngle* to fly freely in all directions. Using a block of wood and hammer, place the block of wood on top of the *Stake* (Do Not hammer on the *Swivel*) and drive into the ground keeping the stake vertically straight.

4 - Assemble the three pole sections

5 - Carefully slide the *Banner* over the sectional pole, starting from the bottom of the *Banner*, insert the pole into the black pole pocket sewn along the inside edge of the material. Make sure the end of the pole is fully inserted into the *Banner* top arch.

6 - Secure *The ArchAngle Banner* to the base by looping the attached cord around the flanged lip located at the base of the pole.

7 - Place the *Base* of the erected banner onto the *Swivel* making sure that the base is fully engaged onto the swivel neck.

### Care instructions

Keep your *ArchAngle Banner* looking nice and lasting longer by following these simple steps:

- Always slowly guide the pole through the sleeve on the banner to avoid damage to the banner or pole
- *The ArchAngle* works well indoors or out. If using outdoors, it is recommended that you do not fly your *ArchAngle Banner* during high winds or bad weather. *The ArchAngle* should be taken down during non-business hours.

### Accessories

Optional accessories are available including: Optional weighted cross base with 360° swivel, water fillable base weights, replacement banners and custom banners.

To order optional accessories visit [www.thearchangle.com](http://www.thearchangle.com).

A Product From:

